

















**LOWEPRO CIRRUS SERIES MATRIX 5-2008** **Still and Digital Video**

								
		Cirrus TLZ 5	Cirrus TLZ 15	Cirrus TLZ 25	Cirrus 100	Cirrus 110	Cirrus 120	Cirrus 140
<b>Canon</b>	DC210/230				•			
	DC310				•			
	DC320				•			
	DC330				•			
	DC50				•			
	EOS 30D w/compact zoom		•				•	
	EOS 40D w/compact zoom		•				•	
	EOS Digital Rebel Xsi/450D w/compact zoom		•				•	
	EOS Digital Rebel Xti/400D w/ compact zoom		•			•		
	FS10					•		
	FS100					•		
	FS11					•		
	HR10					•		
	MV920		•					
	MV930/940/950/960		•			•		
	MVX35i/30i		•					
	MVX430		•					
	MVX450/460		•					
	Optura 300/MVX10i		•					
	PowerShot A540/A550/A560		•					
	PowerShot A570 IS		•					
	PowerShot A640		•					
	PowerShot A650 IS		•					
	PowerShot A700		•					
	PowerShot A720 IS		•					
	PowerShot G9		•					
	PowerShot S5 IS		•					
	PowerShot SX100 IS		•					
	Vixia HF10					•		
	Vixia HF100					•		
	Vixia HG10					•		
	Vixia HR10					•		
	Vixia HV20					•		
	Vixia HV30					•		
	ZR500/600/700		•					
ZR800		•						
ZR830/850		•						
ZR900					•			
ZR930		•						
ZR950		•						
<b>Casio</b>	EXILIM Pro EX-F1		•				•	
<b>Fuji</b>	FinePix IS 1		•					
	FinePix S1000fd	•						
	FinePix S100FS		•			•		
	FinePix S5 Pro w/compact zoom							•
	FinePix S5700	•						
	FinePix S5800	•						
	FinePix S6000		•			•		
	FinePix S6500fd		•			•		
	FinePix S6900		•			•		
	FinePix S700	•						
	FinePix S8000fd	•						
	FinePix S8100fd	•						
	FinePix S9100/9600		•			•		
	<b>Hitachi</b>	DZ-BD70A					•	
DZ-BD7HA						•		
DZ-GX5020A/5080A					•			
DZ-HS300A					•			
DZ-HS500A					•			

\*Availability may vary depending on country and location.









LOWEPRO CIRRUS SERIES MATRIX 5-2008

Still and Digital Video

		      						
		Cirrus TLZ 5	Cirrus TLZ 15	Cirrus TLZ 25	Cirrus 100	Cirrus 110	Cirrus 120	Cirrus 140
	HS300A/500A				•			
<b>JVC</b>	Everio GZ-MG130	•						
	Everio GZ-MG145	•						
	Everio GZ-MG155/255	•						
	Everio GZ-MG26	•						
	Everio GZ-MG27	•						
	Everio GZ-MG555U	•						
	Everio GZ-MG57EK	•						
	Everio GZ-MG77U	•						
	GR-D250	•						
	GR-D33/72/93	•						
	GR-D350AA	•						
	GR-D370	•						
	GR-D650	•						
	GR-D73US	•						
	GR-D750/770/796	•						
	GR-DVM76/96	•						
	GR-DX25/77/95/97	•						
	GZ-MG130	•						
	GZ-MG255	•						
	GZ-MG26	•						
	GZ-MG330/335/365/465	•						
	GZ-MG50S	•						
	<b>Kodak</b>	EasyShare P712	•					
EasyShare P850		•						
EasyShare P880		•						
EasyShare Z1012 IS		•						
EasyShare Z612		•						
EasyShare Z650		•						
EasyShare Z710		•						
EasyShare Z712 IS		•						
EasyShare Z812 IS		•						
EasyShare Z8612 IS	•							
<b>Leica</b>	Diqilux 3				•			
	M8 w/compact zoom		•			•	•	
	V-Lux 1					•		
<b>Minox</b>	DC-6033 WP				•			
<b>Mustek</b>	DV-4500	•						
	MDC-6500z	•						
<b>Nikon</b>	Coolpix 4800	•						
	Coolpix 8800				•			
	Coolpix L5	•						
	Coolpix P80	•						
	D40 w/compact zoom		•			•		
	D50 w/compact zoom		•			•		
	D60 w/compact zoom		•			•		
	D70 w/compact zoom				•			
	D80 w/compact zoom			•			•	
<b>Olympus</b>	E-1 w/compact zoom		•		•			
	E-420 w/compact zoom		•			•		
	E-420 w/pancake 25mm lens				•			
	E-510 w/compact zoom		•			•		
	Evolet E-330 w/compact zoom		•			•		
	Evolet E-400 w/compact zoom		•			•		
	Evolet E410 w/compact zoom		•			•		
	EVOLT E-500 w/compact zoom		•			•		
	SP-510UZ	•						
	SP-550UZ/560UZ	•						
	SP-570UZ				•			

\*Availability may vary depending on country and location.









**LOWEPRO CIRRUS SERIES MATRIX 5-2008** **Still and Digital Video**

		      						
		Cirrus TLZ 5	Cirrus TLZ 15	Cirrus TLZ 25	Cirrus 100	Cirrus 110	Cirrus 120	Cirrus 140
<b>Panasonic</b>	Lumix DMC-FZ18				•			
	Lumix DMC-FZ50		•			•		
	Lumix DMC-FZ7	•						
	Lumix DMC-FZ8	•						
	Lumix DMC-L1 w/compact zoom		•			•		
	Lumix DMC-L10 w/compact zoom		•			•		
	Lumix DMC-LX1	•						
	Lumix DMC-LX2	•						
	Lumix DMC-LZ3/LZ5	•						
	NV-GS1/GS4/GS5	•						
	NV-GS11B/15B	•						
	NV-GS22B/33B/55B	•						
	NV-GS27	•						
	NV-GS50	•						
	PV-DC152/252/352	•						
	PV-GS31	•						
	PV-GS33/GS55	•						
	PV-GS35	•						
	PV-GS50S	•						
	PV-GS9/12/14/15	•						
	PV-GS90				•			
	SDR-H200	•						
	SDR-H40/H60				•			
SDR-S150	•							
SDR-S7	•							
<b>Pentax</b>	*ist D w/compact zoom			•		•		
	*ist DL w/compact zoom		•		•	•		
	*ist DS w/compact zoom		•		•	•		
	*st DS 2 w/compact zoom		•		•	•		
	K100D w/compact zoom		•		•	•		
	K10D w/compact zoom		•		•	•		
	K110D w/compact zoom		•		•	•		
	K200D w/compact zoom		•		•	•		
K20D w/compact zoom		•						
<b>RCA</b>	CDS4100				•			
	CDS6300				•			
<b>Ricoh</b>	GX100 w/finder	•						
<b>Rollei</b>	d-24/d-30/d-530 Flex		•			•		
<b>Samsung</b>	Digimax Pro 815		•		•			
	GX-10 w/compact zoom			•			•	
	GX-1L w/compact zoom		•			•		
	GX-1X w/compact zoom		•			•		
	GX-20 w/compact zoom			•			•	
	SCD180	•						
	SCD363	•						
	SC-DC173				•			
	SC-DC575				•			
	VP-D130	•						
	VP-D323/D325i	•						
	VP-D361i	•						
	VP-D590i	•						
	VP-D907i	•						
VP-D963 WI	•							
<b>Sanyo</b>	VPC-C1E Xacti	•						
	VPC-C40	•						
<b>Sharp</b>	VE-CG30U/40U	•						
	VL-Z1U/Z3U/Z5H/Z7U	•						
<b>Sigma</b>	DP-1	•						

\*Availability may vary depending on country and location.

LOWEPRO CIRRUS SERIES MATRIX 5-2008

Still and Digital Video

		 Cirrus TLZ 5	 Cirrus TLZ 15	 Cirrus TLZ 25	 Cirrus 100	 Cirrus 110	 Cirrus 120	 Cirrus 140
<b>Sony</b>	Alpha DSLR-A300 w/compact zoom		•				•	
	Alpha DSLR-A350 w/compact zoom		•				•	
	Alpha DSLR-A700 w/compact zoom						•	
	DCR-HC18E/20/20E/30/30E/40/40E	•						
	DCR-HC26	•						
	DCR-HC28	•						
	DCR-HC35E	•						
	DCR-HC36	•						
	DCR-HC38/46/HC48	•			•			
	DCR-HC47E	•						
	DCR-HC52	•						
	DCR-HC90E/96	•			•			
	DCR-PC55	•						
	DCR-PC8	•						
	DCR-SR40	•						
	DCR-SR42/SR62/SR82	•						
	DCR-SR45/SR46/SR85	•						
	DSC-H1, H2, H5	•						
	DSC-H10	•						
	DSC-H3	•						
	DSC-H50	•						
	DSC-H7/H9	•						
	DSC-R1			•		•		
	HDR-CX7				•			
	HVR-A1U						•	
<b>Thomson</b>	VMD-270	•						
<b>Vivitar</b>	V3755	•						
	Vivicam V3200	•						
	Vivicam V3500				•			

\*Availability may vary depending on country and location.